



Specification & Installation instruction



Feature:


<u>.</u> .	Ulu Ulu
Up to 3500 in.lb [400Nm].	L
Clutch for manual adjustments.	UB8000
Maintenance free.	L
Fail safe (battery backup)	UB8030
(on model 010 & 030).	L

- Auxiliary switches (on model 020 & 030).
- IP56 enclosure.

Old Number	
UB8000A	UT000
UB8000A-AUX2	UT020
UB8030A	UT010
UB8030A-AUX2	UT030
UB9000A	WT000
UB9000A-AUX2	WT020
UB9030A	WT010
UB9030A-AUX2	WT030

Technical Data	UT000 UB8000A	UT020 UB8000A -AUX2	UT010 UB8030A	UT030 UB8030A -AUX2	WT000 UB9000A	WT020 UB9000A -AUX2	WT010 UB9030A	WT030 UB9030A -AUX2	
Auxiliary switches	No	Yes (2)	No	Yes (2)	No	Yes (2)	No	Yes (2)	
Fail safe	Ν	lo	Yes		No		Yes		
Torque	1800 in.lb. [200 Nm] at rated voltage 3500 in.lb. [400 Nm] at rated voltage						age		
Running time through 90°	45 sec.					90 sec.			
Feedback	4 to 20 mA or 2 to 10 VDC adjustable								
Power consumption	100 VA								
Power supply	22 to 26 VAC or 28 to 32 VDC								
Electrical connection	18 AWG [0.8 mm ²] minimum								
Inlet bushing	3 inlet bushing of 7/8 in [22.2 mm]								
Control signal	4 wire / 2 position, 5 wire / 3 point floating								
Angle of rotation	0 to 110 degrees, electronically adjustable (factory set with 110° stroke)								
Direction of rotation	Reversible, Clockwise (CW) or Counterclockwise (CCW) (factory set with CW direction)								
Ambient temperature	0°F to +122°F [-18° C to +50° C]								
Storage temperature	-22°F to +122°F [-30° C to +50° C]								
Relative Humidity	5 to 95 % non condensing.								
Weight	26 lbs. [12 kg]								
V	Varning: D	o not pres	ss the clut	ch when a	actuator is	powered			

Dimensions




Caution

We strongly recommend that all neptronic® products be wired to a separate transformer and that transformer shall service only neptronic® products. This precaution will prevent interference with, and/or possible damage to incompatible equipment. When multiple actuators are wired on a single transformer, polarity must be observed. Long wiring runs create voltage drop which may affect the actuator performance.







Exploded view



Wiring Diagrams



PC Board



Stroke adjustment

To adjust the stroke, press and release the reset button to start the auto-stroke process.

The LED should be illuminated.

• First option:

The actuator will then travel in both directions to find it's limit. The LED will extinguish, the process is complete.

Second option:

When the desired end position is reached, press and release the reset button. The actuator will now return back to its original position. (you can also press and release the reset button when It's reaches the original position) The LED will extinguish, the process is complete.