# AP

# Carbon Monoxide Detector Fire Detector



FCO Wall





Œ

**FCO Duct** 

#### **Features**

- Continuous monotoring
- Low zero point drift
- Good stability to poisoning
- Long life sensor
- Modular plug-in technology
- Easy maintenance/calibration
- Manual adressing for RS485 mode (option)
- 4-20mA analog input for external transmitter
- 4-20mA loop-powered or 2-10Vdc output signal

**FCO** 

- Relay output
- Duct mounting
- Integrated heating for less degree than specified operating range

#### **Technical Data**

Gas Carbon Monoxide

Detection principle Electrochemical, diffusion

Stability & resolution

**Repeatability** +/- 3% of reading

Long term output drift

<5% signal loss/year t90 <50 sec.

Response time

+/- 3ppm

**Storage time** 6 months

**Mounting height** 1,5 to 1,8 metres above floor

#### Output signal selectable

(0)4-20mA load < 500ohm overload (0)2-10Vdc load < 50kohm overload Starting point 0/20% prportional, overload and

short-circuit proof

**Relay Output** 

Relay 1 30Vac/dc, 0,5A, pot.free SPDT

Relay 2 Dito SPNO/SPNC Power Cons. 30mA, (0,8VA)

Serial interface RS485/19200Baud 9600 Modb us

**Power supply** 18-28Vac/dc (reverse polarity prot.)

**Power consumption** 22mA, max (0,6VA)

Short time

**Expected lifetime** 5 years, normal operating envirom.

**Humidity range** 

ge
Continuous 15-90% rH non-condensing

0-95%RH non-condensing

Operating range

Continuous -10 up to +50C Short-time -20 up tp +50C

Rating IP65 Protection Class

Pressure range Atmospheric +/-10%

## **Application**

For detection of carbon monoxide (CO) within a wide range of fire detection applications.

Due to the standard analogue signal the CO transmitter is compatible to any electronic analogue control, DDC/PLC control or automation system.

#### **Ordering Codes**

Manual calibration via potentiometer

FCO 050 0-50ppm 4-20mA/2-10Vdc

Calibration and adressing by service Tool

**FCO 050T** 0-50ppm 4-20mA/2-10Vdc

MOD Protocol for Modbus

**CUST** Protocol for customers specifications

GCD Protocol for GCD-seriesREL CO Relay pack see below

**DUCT** Duct Mounting

LCD Two lines, 16 characters each
CAL 2 Calibration Kit for Tox-transmitters

**HEAT** Temp.controlled heating element 3C +/-2C0,3VA

BUZZ Internal warning summer 85dB STAIN Enclosure of stainless steel

**SERV** Service Tool with Keyapad and LCD-display

AIN 4-20mA analogue input GAS 17 Calibration gas 17 liter

**REG** Pressure regulator flow adjusted to 0,5 lit/min.

Warning devices See special datasheet Warning signs See special datasheet



# **Carbon Monoxide Detector Fire Detector**

Cross sensitivity*	Concentration (ppm)	Reaction (ppm)
Acetone, C <sub>3</sub> H <sub>6</sub> O	1000	0
Acetylene, C <sub>2</sub> H <sub>2</sub>	40	80
Ammonia, NH <sub>3</sub> <sup>*</sup>	100	0
Carbon dioxide, CO <sub>2</sub>	5000	0
Chlorine, Cl <sub>2</sub>	2	0
Ethanol, C <sub>2</sub> Ĥ <sub>5</sub> OH	2000	5
Hydrogen, H <sub>2</sub>	100	20
Hydrogen Sulphide, H <sub>2</sub> S	25	0
Iso Propanol, C <sub>3</sub> H <sub>8</sub> O	200	0
Nitric oxide, NO	50	8
Nitrogen dioxide, NO <sub>2</sub>	50	-1,0
Sulphur dioxide, SO <sub>2</sub>	50 <	: 0,5

### **Relay Package**


With the FCO relay package two potential-free contacts are available for the connection to external devices.

The switching thresholds of these relays are selectable via potentiometer in the range of 10 - 90% of CO concentration.


The hysteresis is programmable via jumpers.

Addditionally the relay mode, open-circuit or closed circuit, is selectable.

The status of the two relays is displayde via LED



### **Connecting Diagram**



The two relays are activated in dependence of the gas concentration.

if the gas concentration exceeds the adjusted alarm threshold, the corresponding relay switches on.

If the gas concentration falls below the threshold minus hysteresis, the relay switches off again.

The contact function for relay 2, NC (normally closed) or

NO (normally open), can be selected via the jumper NO/NC.

See fig 1 and 3. Relay 1 is equipped with a change-over contact.

Via the ModBus interface the two alarm thresholds and hysteresis are freely adjustable at the PC within measuring range.

The procedure can be read from the user manual "ModBus Software".

The following parameters are factory-set.

Alarm threshold 1 = Relay 1: 10 ppm Alarm threshold 2 = Relay 2: 20 ppm Switching hysteresis: 3 ppm